


EN

# PSI-X1P800-MIC PSI-X1P1000-MIC

MICRO-INVERTER

---

Installation manual



/// PEIMAR

Il est important de souligner que toutes les spécifications techniques, les informations et les chiffres figurant dans cette fiche technique sont des valeurs estimées. Peimar se réserve le droit de modifier les spécifications techniques, les informations et les chiffres contenus dans ce document à tout moment et sans préavis.

/// PEIMAR

<b>1. Safety .....</b>	<b>6</b>
1.1. General Safety .....	6
1.2. Safety Instructions of PV, Inverter and Grid .....	7
1.2.1. Safety Instructions of PV .....	7
1.2.2. Safety Instructions of Microinverter .....	7
1.2.3. Safety Instructions of Utility Grid .....	9
1.2.4. Inverter backfeed current onto the array .....	9
1.2.5. Safety Instructions of AC trunk cable .....	10
<b>2. Product Overview .....</b>	<b>11</b>
2.1. Microinverter System Description .....	11
2.2. Highlights .....	12
2.3. Appearance .....	13
2.3.1. Overview .....	13
2.3.2. Dimensions .....	13
2.3.3. Terminals of Microinverter .....	14
2.3.4. Symbols on the Label and Microinverter .....	15
<b>3. Preparation before Installation .....</b>	<b>16</b>
3.1. Unpacking and Inspection .....	16
3.1.1. Unpacking .....	16
3.2. Packing Lists .....	16
3.3. Selection of Installation Location .....	17
3.3.1. Environment Requirement .....	17
3.3.2. Installation Angel Requirement .....	19
3.4. Tools Requirement .....	19
3.4.1. Recommended Equipment .....	19
3.4.2. Recommended Equipment .....	20
3.5. AC Branch Circuit Capacity.....	20

---

<b>4. Installation .....</b>	<b>21</b>
4.1. Accessories.....	21
4.2. Microinverter Installation .....	22
4.3. Microinverter System Initiating .....	33
4.3.1. Initiate the System .....	33
4.3.2. Setup Monitoring System .....	34
<b>5. Troubleshooting and Maintenance .....</b>	<b>40</b>
5.1. LED Indicator Status .....	40
5.2. Troubleshooting .....	41
5.3. On-Site Inspection (for qualified installer only) .....	42
5.4. Maintenance .....	43
5.4.1. Maintenance routines .....	43
<b>6. Decommissioning .....</b>	<b>44</b>
6.1. Disassembling the Microinverter .....	44
6.2. Packing the Microinverter .....	45
6.3. Transportation and Storage .....	45
6.4. Disposal of the Microinverter .....	45
<b>7. Technical Data .....</b>	<b>46</b>
<b>8. Wiring diagram .....</b>	<b>48</b>
8.1 230 V AC Single phase .....	48
8.2 120 V / 240 V AC Split phase .....	48
8.3 230 V / 400 V AC Three-Phase .....	49
8.4 120 V / 208 V AC Three-Phase .....	50

# 1. Safety

## 1.1. General Safety

The series inverter has been meticulously designed and thoroughly tested to comply with the relevant state and international safety standards. Nevertheless, like all electrical and electronic equipment, safety precautions must be observed and followed during the installation of the inverter to minimize the risk of personal injury and ensure a safe installation.

Please thoroughly read, comprehend, and strictly adhere to the comprehensive instructions provided in the user manual and any other relevant regulations prior to the installation of the inverter. The safety instructions in this document serve as supplementary guidelines to local laws and regulations.

Peimar shall not be liable for any consequences resulting from the violation of the storage, transportation, installation, and operation regulations outlined in this document. Such consequences include, but are not limited to:

- Inverter damage caused by force majeure events, such as earthquakes, floods, thunderstorms, lightning, fire hazards, volcanic eruptions, and similar events.
- Inverter damage due to human causes.
- Usage or operation of the inverter in violation of local policies or regulations.
- Failure to comply with the operation instructions and safety precautions provided with the product and in this document.
- Improper installation or usage of the inverter in unsuitable environmental or electrical conditions.
- Unauthorized modifications to the product or software.
- Inverter damage occurring during transportation by the customer.
- Storage conditions that do not meet the requirements specified in this document.
- Installation and commissioning performed by unauthorized personnel who lack the necessary licenses or do not comply with state and local regulations.

## 1.2. Safety Instructions of PV, Inverter and Grid

Save these important safety instructions. Failure to follow these safety instructions may result in damage to the inverter and injury or even loss of life.

### 1.2.1. Safety Instructions of PV



#### **DANGER**

---

Lethal danger from electric shock due to the PV!

1. Never touch the positive or negative pole of PV connecting device. Touching both of them at the same time is prohibited as well.
2. Do not ground the positive or negative pole of the PV modules.
3. Only qualified personnel can perform the wiring of the PV modules.



#### **AVERTISSEMENT**

---

1. Make sure that the input DC voltage  $\leq$  Maximum DC input voltage of the microinverter. Overvoltage may cause permanent damage to the Microinverter, which is NOT covered by the warranty.

### 1.2.2. Safety Instructions of Microinverter



#### **DANGER**

---

Risk of electric shock, fire and hot surface!

1. If the equipment runs abnormally, do not use it by force. Otherwise, electric shock or fire may occur.
2. Do not open the enclosure in any case without authorization from Peimar. Unauthorized opening will void the warranty and cause lethal danger or serious injury due to electric shock.
3. Only qualified and experienced electrician can perform the installation, wiring, maintenance of the microinverter following this document and related rules and regulations.

4. Authorized service personnel must use insulated tools and wear protective equipment when installing or working with this equipment.
5. Keep away from flammable, explosive materials to avoid fire disaster.
6. Risk of high-voltage and hot surface! Ensure the device are within the limit of safe voltage potential and temperature before touching any part of the microinverter.

**AVERTISSEMENT**

---

- 1 Check if all components are intact in case of equipment damage during or after installation.

**AVERTISSEMENT**

---

- 1 The installation place should be away from humid or corrosive substance. Avoid installation near extremely hot/cold environment.
2. Please consult the manufacturer for non-standard installation conditions.
3. Make sure that the microinverter is installed under the PV module in case of direct exposure to UV, rain and other harmful weather events.
4. Avoid mounting the microinverter upside down and always install the microinverter guide rail side up.

**AVERTISSEMENT**

---

- 1 Avoid matching microinverters to cables that have been exposed to wet conditions.
2. Avoid connecting batteries or other sources of power supply to each input of the microinverter, as each input is connected to one PV module.
3. The operating conditions shall be within the range of Technical Data listed in this manual.
4. Never connect or disconnect the AC or DC connectors when the microinverter is running. Please turn off the microinverter before any operation of the AC or DC connectors.
5. Make sure that the AC branch circuit is de-energized before servicing.



**ATTENTION**

---

1. Children should be supervised to ensure that they do not play with the appliance.

**NOTICE**

---

1. Before installing and maintaining the equipment, please read the User Manual and Installation Guide.
2. Comply with local safety rules and regulations before all electrical installations
3. All the product labels and nameplate on the microinverter shall be maintained clearly visible.

**1.2.3. Safety Instructions of Utility Grid****NOTICE**

---

1. Only with permissions of local utility grid company, the microinverter can be connected to the grid.
2. The installer must provide Over Current Protection Devices (OCPD) and external disconnect switches.

**1.2.4. Inverter backfeed current onto the array****NOTICE**

---

This requirement protects against overloading of array wiring due to backfeed currents from the inverter.

For example, such currents can be generated when fault conditions allow currents derived from other sources such as the mains or a battery to flow out of the PV input terminals of the inverter. If this backfeed current is limited to the maximum normal current the array can source, wiring and other devices in the current path will be adequately sized to carry the backfeed current without overload. If this backfeed current is not limited to the maximum normal current, providing the value of the max current to the installer is critical to allow determination of any increase in wiring sizes or added overcurrent protection necessary.

### 1.2.5. Safety Instructions of AC trunk cable



#### **DANGER**

---

1. Avoid installing the AC trunk cable connectors while power is connected.



#### **AVERTISSEMENT**


---

1. Check if the AC trunk cable conductors are not damaged. Only when the exposed wires are not damaged, the system can function properly.
2. Install the protective sealing caps on the unused AC connectors,
3. Secure the loose AC trunk cables to reduce tripping hazard.
4. Never leave the AC connectors on the AC trunk cable uncovered.

## 2. Product Overview

### 2.1. Microinverter System Description

A microinverter system is composed of PV grid-connected microinverters, PV modules, and grid. Microinverter data are transmitted to Peimar monitoring platform Peimar Portal.



#### X1P-MIC

The X1P-MIC manages system energy. Microinverters convert the direct current power generated from the PV modules into grid-compatible AC current. They send their operation data and the output information of PV modules to the monitoring platform, including PV voltage, current, power, etc., which is the foundation of the module-level monitoring.

Microinverters are divided into 1 in 1, 2 in 1, 4 in 1, etc., resting with how many PV modules it connects, which means that a microinverter can be linked to 1/2/4 modules separately. This manual focuses on 2 in 1 series.

PV grid-connected microinverter, a module-level solar Microinverter, is capable of effectively solving the single point of failure in the photovoltaic power generation system. The microinverter can work by tracking the maximum DC power point of each PV module, which is known as Maximum Power Point Tracking (MPPT).

The X1-MIC is integrated with MPPT, which means that even though a PV module runs abnormally or is shaded, other modules won't be affected and can operate the unshaded string at maximum efficiency point. This function plays an important role to improve the efficiency of a photovoltaic (PV) generation system.

Furthermore, X1-MIC device only carries a relatively low DC voltage, mitigating the risk of electric shock.

## **PV module**

A PV Module is an assembly of photovoltaic cells, also known as solar cells. To achieve a required voltage and current, a group of PV modules are wired into strings which are called PV arrays. A PV module is the essential component of any PV system that converts sunlight directly into direct current electricity.

## **Grid**

220V / 230V/ 240V grid are supported.

## **Peimar X Portal**


Peimar X Portal is an intelligent, multifunctional monitoring platform that can be accessed either remotely or through a hard wired connection. With the Peimar Cloud, the operators and installers can always view key and up-to-date data and set it remotely. You can log in to your user account at any time through a personal computer, IOS or Android device to view real-time monitoring data or historical data, and perform remote settings as needed

## **2.2. Highlights**


- Max output power up to 1200VA with two independent input channels (MPPT)
- Up to 20 A DC input current to be compatible with high power PV modules
- Built-in industrial grade Wi-Fi module for high reliability
- Safety protection relay integrated
- Support micro-grid, AC coupling solution with existing storage system
- Support the integration of a single-phase microinverter into a three-phase power grid system
- With Reactive Power Control and Rapid Shutdown Function Easy to install and
- maintain with small size, light weight
- IP67 protection class, more reliable.

## 2.3. Appearance


### 2.3.1. Overview



### 2.3.2. Dimensions



### 2.3.3. Terminals of Microinverter



<b>A</b>	Spare ground cable clip	For standby earth connection
<b>B</b>	PV terminal	For PV connection.
<b>C</b>	Indicator	Show the status of the device.
<b>D</b>	Antenna	To receive and transmit Wi-Fi signal.
<b>E</b>	AC terminal	For AC connection.
<b>F</b>	Earth lug	A connection component for electrical devices which need grounding (perferred grounding method).

### 2.3.4. Symbols on the Label and Microinverter



**CE MARK**

The microinverter complies with the requirements of the applicable CE guidelines.



**BEWARE OF HOT SURFACE**

The microinverter can become hot during operation. Avoid contact during operation.



**DANGEROUS ELECTRIC VOLTAGE**

Danger to life due to high voltages in the Microinverter!



**WARNING, DANGER!**

Risk of electric shock!



**DANGER TO LIFE due to high voltage!**

There is residual voltage in the inverter which needs 5 min to discharge. Wait for 5 min before you open the upper lid or the DC lid.



**This device MUST NOT be disposed as a municipal waste.**

The microinverter can not be disposed together with the household waste. Disposal information can be found in the enclosed documentation.



**INSTRUCTIONS**

Refer to the present manual for inverter installation, operation, maintenance, and troubleshooting instructions.


### 3. Preparation before Installation

#### 3.1. Unpacking and Inspection

##### 3.1.1. Unpacking

The microinverter undergoes 100% testing and inspection before shipping from the manufacturing facility. However, transport damage may still occur. Before unpacking the Microinverter, please verify that the model and outer packing materials for damage, such as holes and cracks.

Please unpack the microinverter according to the following figure.



Be careful when dealing with all package materials which may be reused for storage and relocation of the microinverter in the future.

Upon opening the package, check whether the appearance of the microinverter is damaged or lack any accessories. If any damage is found or any parts are missing, contact your dealer immediately.

#### 3.2. Packing Lists

Specifications	Quantity
Inverter	1
Installation map	1
Documents	1



**Sold separately:**

<b>Specifications</b>	<b>Quantity</b>
AC trunk end cap	1
AC trunk connector	1
AC trunk port disconnect tool	1
1.2 m / 2 m / 2.4 m AC trunk cable	1
AC end cable-M	1
Male connector	1
Female connector	1
DC extension cable	1

\* Refer to the actual delivery for the optional accessories.




**3.3. Selection of Installation Location**

The installation location selected for the microinverter is quite critical in the aspect of the guarantee of machine safety, service life and performance.

- It has the IP67 ingress protection, which allows it to be installed outdoor;
- The installation position shall be convenient for wiring connection, operation and maintenance.

**3.3.1. Environment Requirement**

- The ambient temperature: -40°C to +65°C;
- The humidity shall be between 0-100%;
- Do not install the microinverter in the areas where the altitude exceeds 3000 m;
- Install the microinverter in a well-ventilated environment for heat dissipation;
- Do not install the microinverter in areas with flammable, explosive and corrosive materials;
- Do not install the microinverter in areas near combustibles and antennas;
- Install all microinverters and DC connectors under the PV modules.
- Avoid direct exposure to UV, rain and other harmful weather events.
- Avoid electromagnetic interference in case of the malfunction of electronic equipment.



**NOTICE**

For outdoor-installation, precautions against direct-sunlight, rain -exposure and snow-accumulation are-recommended.


Exposure to direct sunlight raises the temperature inside the device. This temperature rise poses no safety risks, but may impact the device performance.

### 3.3.2. Installation Angel Requirement



#### NOTICE

Install the microinverter on the bracket. Make sure the bracket is parallel with the rail.



### 3.4. Tools Requirement

#### 3.4.1. Recommended Equipment

Installation tools include but are not limited to the following recommended ones. If necessary, use other auxiliary tools on site.

Specifications	Quantity
Cable tie	1
Multimeter	1
Measuring tape	1
Utility knife	1
Marker	1
Torque screwdriver (Phillips head: M4)	1
Diagonal pliers	1
Allen key	1
Wire stripper	1
Wire cutter	1
Safety gloves	1
Safety boots	1
Safety goggles	1
Anti-dust mask	1

### 3.4.2. Recommended Equipment

1	AC circuit breaker	Current: 50A for 10 AWG/40 A for 12 AWG (If there are additional safety regulations, please refer to the local safety regulations)
2	Guide rail	According to actual needs
3	Sliding block	Matching with the guide rail
4	Screw	Matching with the guide rail
5	AC cable	4-6 mm <sup>2</sup> ; three-core soft wire cable

### 3.5. AC Branch Circuit Capacity

PSI-X1-Micro can be used with the provided AC Trunk Cable and AC Trunk Connectors. The maximum number of microinverters on each AC branch is listed as follows:

		Maximum over current protection device
Maximum number per 12AWG branch	7 A (220V) 7 A (230V) 7 A (240V)	40 A
Maximum number per 10AWG branch	8 A (220V) 9 A (230V) 9 A (240V)	50 A




#### NOTICE

An AC branch can connect to 1 in 1/2 in 1/4 in 1 microinverters at the same time, provided that the total current is less than the AC branch circuit capacity stipulated in local rules and regulations. How many microinverters that each AC branch can connect depends on the current-carrying capacity of the cable.

## 4. Installation

### 4.1. Accessories



	PSI-XMIC-CAB240AC-10	
A	PSI-XMIC-CAB200AC-10 PSI-XMIC-CAB160AC-10 PSI-XMIC-CAB120AC-10	1.2 m / 2 m / 2.4 m AC trunk cable.
B		DC extension cable (if necessary)
C	PSI-XMIC-CONN-TAC	AC trunk connector
D	PSI-XMIC-ENDCAP	AC trunk end cap
E	PSI-XMIC-DISCTOOL	AC trunk port disconnect tool
F	PSI-XMIC-CONN-FAC	Female connector
G	PSI-XMIC-CONN-MAC	Male connector
H	PSI-XMIC-CABM500AC-10	AC end cable-M



**NOTICE**


The above accessories are not included in the package and need to be purchased separately.

**4.2. Microinverter Installation**



**WARNING, DANGER!**


Avoiding pulling or holding the AC cable with your hand directly. Hold the handle of the microinverter instead.





**WARNING, DANGER!**

Pay attention to the earth lug. Risk of hand injury!



**Rail Installation**

- 1) The installer has to install the rails on the roof and fix them with screws to ensure a stable installation environment for microinverters.

**Plan the Number and Installation Location of Microinverters**

- 1) Arrange the installation number and location of each microinverter according to the layout of the photovoltaic system.
- 2) Use a marker to mark the suitable areas of the rail for installing microinverters.




**NOTICE**

Please adjust the terminal location on the AC trunk cable according to the distance between microinverters for a stable connection.

### Install the Microinverter on the Rail

- 1) Place the sliding bolcks and screws on the maked place of the rail.
- 2) Hang on microinverters. The sliver cover side with performance table of the microinverter shall be placed upwards.
- 3) Tighten the screws.



#### NOTICE

Choose the screwdriver according to the corresponding screws of the rail.


### Place AC Trunk Cable on the Rail

- a) Place the AC trunk connector on the rail inwards (as shown below) and band it with cable ties.




#### NOTICE

In order to better fix the AC trunk cable, it is recommended to use more cable ties to band the AC trunk cable. Choose the cable tie according to the rail width and the length of self-purchased accessories.







- b) Plug the male terminal of AC trunk cable into the female terminal of AC trunk connector.



- c) Band the AC trunk cable with cable ties. In order to better fix the AC cable, it is recommended to use more cable ties to band the AC cable.



- d) Repeat this step in sequence.






**NOTICE**

When connecting AC cables in the middle, please follow the diagram below.

- e) Cover vacant AC ports with AC trunk end cap.




**NOTICE**

The male head of the AC trunk connector connected to the first microinverter needs to be connected with the AC Trunk End Cap.

**Microinverter Connection**

- a) Plug the AC connector of the microinverter into the trunk cable connector. The connection is completed when you hear a "click".






**NOTICE**

Avoid placing AC connectors nearby any drainage channels.

If you need to disconnect the AC connector from the AC cable, use the AC Trunk Port Disconnect Tool (see packing list).

**Complete the Installation Map**

- a) Remove the serial number label on the machine and attach to the installation map following the planned installation place.



Microinverter Installation Map														
Model name / Version	Project Name						Customer information					Address information		
	Project Name: Address: Site: Mounting:													
Grid	1	2	3	4	5	6	7	8	9	10	11	12	13	14
A														
B														
C														




**NOTICE**

Choose the suitable grounding method according to local safety regulations.

We provide two grounding methods for this series of microinverters. If the earth lug doesn't touch the rail or the rail is not on the ground, please try method 2.


**Method 1 (major grounding method)**

Let the earth lug touch the rail.



**Method 2**

Strip the PE cable, place the PE cable on the rail and fix it with screws



## Connect Multiple PV Modules to Microinverter



### NOTICE


At least two or three trained and experienced workers are required to finish this step.



### WARNING, DANGER!

Please connect PV terminals in the correct way. Reverse connection may damage the microinverter!


- a) One or two workers hold the PV panel nearby microinverter, while the other one connects PV terminals of each microinverter to the corresponding DC cable of PV module.





### NOTICE

If the panels are too far from the microinverter, please use DC extension cables for connection.

- b) Cover the PV modules above the microinverters and fix the PV panels.



- c) Insert the AC end cable-M to the last female connector of the AC trunk connector, and connect the other end of AC end cable-M to the distribution box (L, N and PE cables must be connected accordingly).



AC end cable-M



**NOTICE**

The length of AC end cable shall depends on the actual installation scene.




**NOTICE**


If you didn't buy AC end cable-M, please follow the procedures below to make the wire before connecting to the distribution box.

Please use 4-6 mm<sup>2</sup> three core soft wire cable. Single core hard wire cable cannot be used in the following steps.


- d) Disassemble the Male connector into four parts: part I, part II, part III and part IV.
- e) Strip the AC end cable-M (about 40 mm) and then strip L, N and PE cables (about 9 mm) inside the AC end cable-M.





- f) Connect the male pin contacts to L, N and PE cables and crimp pin contacts.



- g) Thread part I, part II and part III into the AC end cable-M. Thread L, N and PE cables into the corresponding hole of part IV. Screw down part IV with part I.



- h) Insert the AC end cable-M to the last female connector of the AC trunk connector, and connect the other end of AC end cable-M to the distribution box (L, N and PE cables must be connected accordingly).



AC end cable-M



### **4.3. Microinverter System Initiating**

#### **4.3.1. Initiate the System**

Checking before Power-on

- Check the device installed correctly and securely;
- All AC cables are connected correctly and securely;
- All DC cables are connected correctly and securely;
- Make sure all photovoltaic panels are connected correctly and securely;
- Make sure all the connectors which are not used should be sealed by covers;
- Make sure the microinverter is installed under the PV modules;
- Make sure all the connectors are free of water.

First turn on the AC breaker on the branch circuit and then the main AC breaker of the house. Wait for about 2 minutes until the system is initiated.

### 4.3.2. Setup Monitoring System

#### Step 1: Scan the QR Code

Scan the QR code to download the monitoring app.



App Store






Google Play Store



Peimar X Portal


#### Step 2: Create an Account

Click on [Sign Up] to create an account, fill in your information, and then log in to your account.



### Step 3: Create a Site

Click on [+] in the main interface, then fill in the corresponding information to create your site.




### NOTICE

The app registration through creating a new account is intended for end users. If you wish to request an agent account, please contact technical support.

### Step 4: Add device

Following the previous step, you will enter the [Add Device] interface. Input the QR code on the device, and then click [Add Device].




### NOTICE

If scanning the QR code step fails, then try to scan the one dimensional code. Scanning one dimensional code may lead to inaccurate scan results).

## Step 5: Wi-Fi Setup

In this step, you will start to configure Wi-Fi.




### NOTICE

If the Wi-Fi configuration fails, please refer to the PSI-X-H-WIFI-3.0 installation manual for troubleshooting.


## Step 6: Verify Layout Information

After the Wi-Fi configuration, click on [Layout] in the [Power Station Detail] interface and select [Edit now].



### Step 7: Customize the layout of the components

Select the corresponding device to customize the component layout and then [Save] the settings. Afterwards, users can view the power and connection status of each component, and check the total power at the bottom.



### NOTICE

Layout feature is available after WiFi configuration succeeds, please ensure that Wi-Fi is configured successfully before check layout information.

## 5. Troubleshooting and Maintenance

### 5.1. LED Indicator Status

LED Indicator Status	Description
Yellow light flash	Microinverter startup. If the light flashes once in 1s, flashes in 10s or still flashes after 10s, microinverter startup fails or DSP firmware is upgrading.
Yellow light steady on	Microinverter standby/self-checking.
Green light flash (5s)	Normal operation; normal AC grid; communicating with router.
Green light flash (2s)	Normal operation; normal AC grid; no connection with router.
Red light flash (2s)	No AC grid or AC grid outside the regulatory range.
Red light steady on	Error: non-grid abnormal fault. Machine fault like grounding detection fault and PV side fault.

About 10s after connection with DC power, the light turns yellow;

The yellow light flashes for 10s continuously and then keeps steady on which stands for microinverter self-check;

Afterwards, if the system is not powered on, the red light will flash, indicating for no grid existence;

After microinverter connects with DC power for the first time, red light flashes indicates for errors during microinverter startup.



## 5.2. Troubleshooting

This section contains information and procedures for resolving possible problems with the Microinverter , and provides the troubleshooting tips to identify and solve most problems that may occur. Please check the warning or fault information on the App and read the suggested solutions below when error occurs. Contact Peimar Assistance for further assistance. Please be prepared to describe the details of your system installation and provide the model and serial number of the Microinverter.

CODE	FAULTS	DIAGNOSIS AND SOLUTIONS
IE0001	TzFault	Over Current Fault. Wait for about 10 seconds to check if the inverter is back to normal. Disconnect the DC switch and restart the inverter. Or seek help from us.
IE0002	IE0002	Grid Lost Fault. Check if the mains cable is loose. Wait for a while and the system will reconnect when the utility is back to normal. Or seek help from us.
IE0003	GridVoltFault	Grid Voltage Out of Range. Check if the mains cable is loose. Wait for a while and the system will reconnect when the utility is back to normal. Or seek help from us.
IE0004	GridFreqFault	Grid Frequency Out of Range. Wait for a while and the system will reconnect when the utility is back to normal. Or seek help from us.
IE0005	PvVoltFault	PV Voltage Fault. Check whether the PV is overvoltage. Or seek help from us.
IE0006	BusVoltFault	DC Bus Voltage Out of Normal Range. Check if the PV input voltage is within the operating range of the inverter. Disconnect PV wiring and reconnect. Or seek help from us.
IE0008	GridVolt10MFault	Grid Overvoltage for Ten Minutes Fault. The system will reconnect when the utility is back to normal. Or seek help from us.
IE0009	DclnjOCP	DCI Overcurrent Protection Fault. Wait for a while to check if the inverter is back to normal. Or seek help from us.

IE00011	SW OCP Fault	Software Overcurrent Protection Fault. Wait for a while to check if the inverter is back to normal. Disconnect PV and grid, then reconnect. Or seek help from us.
IE0013	IsoFault	Isolation Fault. Check the connections of the inverter. Or seek help from us.
IE0014	TempFault	Over Temperature Fault. Check if the inverter and the ambient temperature exceeds the operating range. Or seek help from us.
IE0028	EepromFault	DSP EEPROM Fault. Disconnect PV wiring and reconnect. Or seek help from us.
IE0030	PvConnDirFault	PV Direction Fault. Check if the PV+/- sides are connected correctly. Or seek help from us.
IE0031	GridRelayFault	Relay Fault. Check the grid connection. Restart the inverter. Or seek help from us.
IE0036	PowerTypeFault	PowerTypeFault: Check the version of Module and DSP. Check the product SN number. Or seek help from us.

### 5.3. On-Site Inspection (for qualified installer only)

Follow the steps below to troubleshoot a malfunctioning microinverter.

Check the voltage and frequency of utility do not exceed the range described in Technical Data of this manual.

Check the connection to the utility grid.



#### **WARNING, DANGER!**

Risk of electric shock! Prior to servicing, always de-energize the AC branch circuit first. Avoid disconnecting the DC connectors under load.

Check the connection between microinverters on the AC branch circuit.

Check if all the AC breakers runs normally and are closed.

Check the DC connection between microinverters and the PV modules.

Check the DC voltage of PV modules is within the range decribed in Technical Data of this manual.

If the microinverter remains malfunctioning after the above steps, please consult our service support or apply for machine replacement.



**WARNING, DANGER!**

Never repair the malfunctioning mircoinverter by yourself!

**5.4. Maintenance**

Regular maintenance is required for the Microinverter. The table of “Proposal of Maintenance” below lists the operational maintenance for expressing the optimum device performance. More frequent maintenance service is needed in the worse work environment. Please make records of the maintenance.



**WARNING, DANGER!**

Only qualified person can perform the maintenance for the Microinverter. Only use the spare parts and accessories approved by Peimar for maintenance.


**5.4.1. Maintenance routines**

Item	Check Notes	Maintenance Inerval
Safety check	Check the items mentioned in section 1 “Safety” The safety check shall be performed by manufacturer’s qualified person who has adequate training, knowledge, and practical experience.	Every 12 months
Indicators	Check if the indicators of the microinverter are in normal state. Check if the display of the microinverter is normal.	Every 6 months
Electrical connection	Ensure that all cables are firmly connected. Check the integrity of the cables, ensuring that there are no scratches on the parts touching the metallic surface. Verify that the sealing caps on idle terminals are not falling off.	Every 6 months

## 6. Decommissioning

### 6.1. Disassembling the Microinverter

- a) To disassembling the microinverter
- De-energize the AC breaker.
  - Dismount the PV module from the guide rail for meter detection.
  - Use a meter to check the DC cables and make sure no current flow exists in the wires between microinverter and module.
  - Use an AC disconnect tool to remove AC sub connectors.
  - Screw off the screw of microinverter and remove the device from the guide rail.



- b) To replace the microinverter in our monitoring platform
- Use APP to scan or type in the SN of the microinverter to be used.
  - Make sure the AC breaker is turned off and install the microinverter according to Installation Steps described in this manual.
  - In Peimar X Portal app, unbind the original microinverter and bind new model

## 6.2. Packing the Microinverter

- Load the microinverter into the original packing material if possible.
- If the original packing material is not available, you can also use the packing material which meets the following requirements:
  - Suitable for the weight of product.
  - Easy to carry
  - Be capable of being closed completely

## 6.3. Transportation and Storage

If the microinverter is not put into use immediately, the transportation and storage requirements needs to be met:

### Transportation

- Observe the caution signs on the packaging of microinverter before transportation.
- Wear protective gloves when carrying the equipment by hand to prevent injuries.

### Storage

- The microinverter must be stored indoors.
- Do not remove the original packaging material and check the outer packaging material regularly.
- The storage temperature should be between  $-40^{\circ}\text{C}$  and  $+65^{\circ}\text{C}$ . The humidity should be between 0% and 100%.
- Stack the microinverter in accordance with the caution signs on the microinverter carton to prevent their falling down and device damage. Do not place it upside down.

## 6.4. Disposal of the Microinverter

Please dispose of the Microinverters or accessories in accordance with the disposal regulations for electronic waste applied at the installation site.

## 7. Technical Data

DC Input	PSI-X1P800-MIC	PSI-X1P1000-MIC
Max. recommended DC power	320-540 W	400 - 670 W
Max. PV voltage	60 V	
MPPT voltage range	22 - 60 V	
Nominal input voltage	33 V	
Max. PV current	2 x 15 A	2 x 20 A
Isc PV array short circuit current	2 x 20 A	2 x 25 A
Max inverter backfeed current to the array	0 A	
Start output voltage	22 V	
No. of MPPT trackers	2	
Strings per MPPT tracker	1	

### AC Output

Rated output apparent power	800 VA	1000 VA
Maximum continuous output power	800 VA	1000 VA
Nominal AC voltage <sup>1</sup>	220 or 230 or 240 / 180 - 264 V	
Nominal AC frequency <sup>2</sup>	50 / 45 - 55 or 60 / 55 - 65 Hz	
Rated output current	3.64 A (220V)	4.55 A (220V)
	3.48 A (230V)	4.35 A (230V)
	3.34 A (240V)	4.17 A (240V)
Power factor range	> 0.99 (-0.8 ~ 0.8 adjustable)	
Current inrush	9 A (230V)	
Max output fault current	9 A (240V)	
Max output overcurrent protection	12 A	
Total harmonic distortion	< 3 %	

<sup>1</sup> Nominal AC voltage/frequency range may vary according to local rules and regulations.

<sup>2</sup> Refer to local rules and regulations for the specific number of microinverters per branch.

**Efficiency, Safety and Protection**


MPPT efficiency	99.9 %
Maximum efficiency	96.5 %
Protection class	CA: I; CC: II/III
Ingress protection rating	IP67
Noise emission(typical)	< 25 dB
Operating temperature range	-40 ~ 65 °C (> 45 Derating)
Humidity	0 ~ 100 %
Storage temperature	-40 ~ 65 °C

**Generic Data**


Dimensions (W/H/D)	260 x 212 x 40 mm
Net weight	4.1 kg
Heat dissipation treatment	Natural convection
Communication interface	Wi-Fi

## 8. Wiring diagram

### 8.1 230 V AC Single phase




### 8.2 120 V / 240 V AC Split phase






### 8.3 230 V / 400 V AC Three-Phase



### 8.4 120 V / 208 V AC Three-Phase





/// PEIMAR



[info@peimar.com](mailto:info@peimar.com) | [www.peimar.com](http://www.peimar.com)