

EN

PSI-XMIC-ECC

GATEWAY (ECC)

Installation Manual



/// PEIMAR

Il est important de souligner que toutes les spécifications techniques, les informations et les chiffres figurant dans cette fiche technique sont des valeurs estimées. Peimar se réserve le droit de modifier les spécifications techniques, les informations et les chiffres contenus dans ce document à tout moment et sans préavis.

/// PEIMAR

1. Safety	6
1.1. Read this First	6
1.2. Safety instructions	7
2. ECC System	8
2.1. ECC System Description	8
2.2. Highlights	9
2.3. Appearance	10
2.3.1. Overview	10
2.3.2. Dimensions	11
2.3.3. Symbols on the Label and ECC	11
3. Interface Description	12
3.1. Interface Layout	12
3.2. Terminal Use	13
3.2.1. Wi-Fi antenna	13
3.2.2. Power	14
3.2.3. DI	14
3.2.4. AI	15
3.2.5. Ethernet	16
3.2.6. DO port	17
3.2.7. RST	19
3.2.8. USB port	20
3.2.9. RS485 port-4	20
3.2.10. RS485 port-3	21
3.2.11. RS485 port-2	24
3.2.12. RS485 port-1	26
3.2.13. 4G antenna	29
3.2.14. SIM card slot	29
3.2.15. TF card slot	29
3.2.16. AP button	30
4 Installation Preparation	31

4.1.	Unpacking	31
4.2.	Packing List	31
4.3.	Selection of Installation Location.....	32
4.3.1.	Environment Requirement	32
4.3.2.	Environment Requirement	33
4.4.	Tools Requirement	33
4.4.1.	Recommended Equipment	33
4.4.2.	Additionally Required Items	34
4.5.	System Installation Steps	34
5.	Installation	35
5.1.	Indoor Installation.....	35
5.1.1.	Installation method 1 (on the wall):.....	35
5.1.2.	Installation method 2 (on the platform)	37
5.2.	Outdoor Installation	39
5.3.	APP Operation	39
5.3.1.	Bind microinverter	44
5.3.2.	Microinverter data	44
5.3.3.	On-site inspection	45
6	Troubleshooting and Maintenance	46
6.1.	LED Indicator	46
6.2.	Maintenance	48
6.2.1.	Maintenance routines	48
6.2.2.	Upgrading Firmware	48
6.2.3	Device Replacement	49
7.	Decommissioning	50
7.1.	Disassembling the Gateway	50
7.2.	Packing the Gateway	50
7.3.	Transportation and Storage	50
7.4.	Disposal of the Gateway	51
8.	Technical Data	52

1. Safety

1.1. Read this First

Gateway ECC is well designed and tested to meet all applicable states and international safety standards. However, like all electrical and electronic equipment, safety precautions must be observed and followed during the installation of the ECC to reduce the risk of personal injury and to ensure a safe installation.

Before installing the device, the installer must carefully read, fully understand and strictly follow the detailed instruction of the user manual and other related regulations. And the safety instructions in this document are only supplements to local laws and regulations.

Peimar shall not be liable for any consequences caused by the violation of the storage, transportation, installation, and operation regulations specified in this document, including, but not limited to:

- ECC damage due to force majeure, such as earthquake, flooding, thunderstorm, lightning, fire hazard, volcanic eruption, etc.
- ECC damage due to man-made cause.
- ECC used or operated against any items in local policy.
- Failure to follow the operation instructions and safety precautions on the product and in this document.
- Installation and use under improper environment or electrical condition.
- Unauthorized modifications to the product or software.
- ECC damage caused during transportation by the customer.
- Storage conditions that do not meet the requirements specified in this document.
- Installation and commissioning operated by unauthorized personnel who are not licensed and /or satisfy state and local jurisdiction regulations.

1.2. Safety instructions

Save these important safety instructions. Failure to do so may result in damage to the ECC and injury.



RF EXPOSURE WARNING

- Install and operate the device in accordance with provided instructions.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the equipment & your body.
- End-users and installers must be provided with antenna installation instructions and equipment operating conditions for satisfying RF exposure compliance.




CAUTION

- Before installation, ensure all power of the device has been cut off.
- Do not dismantle or scrap by force.
- Strictly follow the installation guide to connect cables and the enclosure must be well locked before the device is electrified.
- Unauthorized opening and cable connection will void the warranty and cause lethal danger or serious injury due to electric shock.
- Refer to the corresponding installation guide for related safety requirements when it is connected to other devices.
- Anti-static measures should be taken to decrease the damage of static electricity to electronic components.
- Keep away from flammable, explosive materials.
- All the product labels and nameplate on the device shall be maintained clearly visible.

The full text of the EU declaration of conformity is available at the following internet address: www.peimar.com

2. ECC System

2.1. ECC System Description



ECC (energy control center)

ECC is a crucial component in this ECC system, functioning as a communication gateway. It gathers the operation data of the system and uploads the data to Peimar X Portal, establishing a foundation for data monitoring and remote operation.

Microinverter

Currently, we developed PSI-X1-MIC is applicable to Wi-Fi version, and ECC only needs to be connected to meter.

PV module

PV Module is an assembly of photovoltaic cells, also known as solar cells. To achieve a required voltage and current, a group of PV modules are wired into large array that called PV array. A PV module is the essential component of any PV system that converts sunlight directly into direct current electricity.

Peimar X Portal

Le Peimar X Portal est une plateforme de surveillance intelligente et multifonctionnelle, accessible à distance ou via une connexion filaire. Grâce au Peimar Cloud, les opérateurs et installateurs peuvent toujours consulter les données clés et à jour et les configurer à distance. Vous pouvez vous connecter à votre compte utilisateur à tout moment via un




ordinateur personnel, un appareil IOS ou Android pour consulter les données de surveillance en temps réel ou historiques, et effectuer des réglages à distance selon les besoins.

2.2. Highlights

- Load consumption monitoring
- Flexible networking with Wi-Fi, 4G and Ethernet
- 5V USB port available
- Internal relay available to control external devices
- Support seamless communication with peripherals through RS485 and Ethernet
- Support remote operation and maintenance


2.3. Apparence

2.3.1. Overview



4G Antenna	To receive and transmit 4G signal.
WiFi Antenna	To receive and transmit WiFi signal.
Indicator	Show the status of the device.
Type label	Type label clearly identifies the device type, serial number, specific DC/AC parameters, certification, etc.
Interface port	Interface port is used for communication connection (like WiFi), power connection, grid connection and other functions.

2.3.2. Dimensions



2.3.3. Symbols on the Label and ECC



The ECC complies with the requirements of the applicable CE guidelines.



This device MUST NOT be disposed of as municipal waste.

Do not dispose of the ECC together with household waste.






INSTRUCTIONS

Read the enclosed documentations.

3. Interface Description

3.1. Interface Layout




A	Wi-Fi antenna	1 string for connecting to the router
B	Power	Output voltage: 11.4 ~ 12.6 V. Power supply adapter with round tip
C	DI	4 strings for DRM including DRM0/5/6/7/8 which responds according to grid-connection needs
D	AI	2 strings
E	Ethernet	10/100M network port for connecting to the router
F	DO port	2 active DO strings for dry contact and adapter box
G	RST	Long press to restart ECC
H	USB port	1-string standard USB for local upgrade
I	RS485 port-4	For use with adapter box
J	RS485 port-3	For communication with energy storage system
K	RS485 port-2	For Modbus to be connected with third-party hosts
L	RS485 port-1	For communicating with ECC-PLC and wired meter
M	4G antenna	1 string for connecting to the router
N	SIM card slot	For 4G (Cat M1) SIM card installation
O	TF card slot	Supported maximum capacity: 64 GB for TF card installation to realize data storage
P	AP button	For activating hotspot of ECC and long press 10 second to clear the networking information

3.2. Terminal Use



3.2.1. Wi-Fi antenna

There are 3 methods of connecting ECC to router. WiFi antenna is the first method of connection between ECC and router in a wireless way.



3.2.2. Power



Plug in the power adapter to power on or off ECC. The output voltage is 11.4 ~ 12.6 V.




Plug the power adapter into the socket

3.2.3. DI

There are 4 strings of DI ports for DRM including DRM0/5/6/7/8 which responds according to grid-connection needs.





Docking terminal




3.2.4. AI

There are 2 strings of AI ports.





Docking terminal



3.2.5. Ethernet


There are 3 methods of connecting ECC to router. Ethernet is the second method of connection between ECC and router in wired way. For stable communication between ECC and router, ethernet cable connection is recommended.






3.2.6. DO port


There are 2 strings of active DO ports (12 V) used for dry contact and adapter box.






3.2.7. RST

RST stands for the restart button. Long press the button to restart the system.




3.2.8. USB port

USB port is designed for local upgrade. There is only 1 string of standard USB.




3.2.9. RS485 port-4

There are 4 strings of RS485. RS485 port-4 is used with adapter box for communication.




NOTICE


For adapter box installation, please refer to the Quick Installation Guide or User Manual of Adapter Box.



3.2.10. RS485 port-3



There are 4 strings of RS485. RS485 port-3 is used for AC-coupling communication with energy storage system.






NOTICE

To increase the communication performance, we recommend using shielded twisted pairs (STP). If you choose to use STP, please strip the wire and twist it, and then connect to the GND port of the plug-in terminal A (as shown below).



3.2.11. RS485 port-2



There are 4 strings of RS485. RS485 port-2 is used for modbus communication with the third party host (to measure wind speed, temperature and radiation strength).






NOTICE

To increase the communication performance, we recommend using shielded twisted pairs (STP). If you choose to use STP, please strip the wire and twist it, and then connect to the GND port of the plug-in terminal A (as shown below).



3.2.12. RS485 port-1


There are 4 strings of RS485. RS485 port-1 is used with wired meters and to communicate with ECC-PLC and wired meter.






NOTICE

To increase the communication performance, we recommend using shielded twisted pairs (STP). If you choose to use STP, please strip the wire and twist it, and then connect to the GND port of the plug-in terminal A (as shown below).



⊖ M2

Ⓒ 0.4±.1 N·m






NOTICE


- To connect to meter, we recommend the wire diameter ranging from 0.5-1.5 mm² and the wire length depends on the actual installation conditions.
- For meter installation, please refer to the Quick Installation Guide or User Manual of Meter.

ECC - meter - PSI-X1-MIC




3.2.13. 4G antenna

There are 3 methods of connecting ECC to router. 4G antenna is the third method of connection between ECC and router in a wireless way.




3.2.14. SIM card slot

SIM card slot is applied to install SIM card.




3.2.15. TF card slot

TF card slot is applied for TF card installation, thereby achieving data storage.



3.2.16. AP button

AP is a networking button. Click the button and the hotspot will be activated for 1 hour, and the hotspot will be turned off by default after 1 hour. Click the button again to turn on it; Long pree 10s to clear the networking information.




4 Installation Preparation

4.1. Unpacking

The ECC undergoes 100% testing and inspection before shipping from the manufacturing facility. However, transport damage may still occur. Before unpacking the ECC, please verify that the model and outer packing materials for damage, such as holes and cracks.

Unpacking the ECC according to the following figure:



- Be careful when dealing with all package materials which may be reused for storage and relocation of the ECC in the future.
- Upon opening the package, check whether the appearance of the ECC is damaged or lack of accessories. If any damage is found or any parts are missing, contact your dealer immediately.

4.2. Packing List

Spécifications	Quantité
ECC	1
Bracket	1
Documents	1
Self-tapping screw	3
Expansion tube	3
Docking terminal	1
Plug-in terminal A	3
Plug-in terminal B	1
RJ45 terminal	2
Power adapter (optional)	1



REMARQUE

1. Select the power adapter according to the socket in the installation site; The length of power adapter wire is 1.2 m. If the wire length doesn't meet the installation requirement, please use an appropriate power strip or choose an installation site near the socket.
2. Refer to the actual delivery for the optional accessories.



4.3. Selection of Installation Location


The installation location selected for the ECC is quite critical in the aspect of the guarantee of machine safety, service life and performance.

- It has the IP20 ingress protection, which allows it to be installed outdoor;
- The installation position shall be convenient for wiring connection, operation and maintenance.

4.3.1. Environment Requirement


- The ambient temperature: -20°C to +60°C;
- The humidity shall be between 5%-95%;
- Do not install the ECC in the areas where the altitude exceeds 2000 m;
- Install the ECC in a well-ventilated environment for heat dissipation;
- Do not install the ECC in areas with flammable, explosive and corrosive materials;
- Do not install the ECC in areas near combustibles and antenna;
- Install all ECCs and DC connectors under the PV modules.
- Avoid direct exposure to UV, rain and other harmful weather events.
- Avoid electromagnetic interference in case of the malfunction of electronic equipment.





4.3.2. Environment Requirement

For Wi-Fi mode, the longest connection distance between the router and the device should be no more than 100 m; if there is a wall between the router and the device, the longest connection distance is 20 m.



4.4. Tools Requirement

4.4.1. Recommended Equipment

Installation tools include but are not limited to the following recommended ones. If necessary, use other auxiliary tools on site.

Spécifications

Hammer drill

Marker

Crimping tool for RJ45

Diagonal pliers

Rubber mallet

Torque screwdriver (Phillips head: ST4.2)
(Flat head: M2)

 Wire stripper

 Safety gloves

 Safety boots

 Safety goggles

 Anti-dust mask

4.4.2. Additionally Required Items

Required Material	Type	Conductor Cross-section
Communication cable	Network cable CAT5	4 mm ²
RJ45 terminal	Standard	/

4.5. System Installation Steps

Step 1 to 6 have to be done on site. Step 7 to 9 can be finished either on site or at home. Step 6 must be finished correctly to create site on Peimar X Portal.

1. Install the PV modules and microinverters (refer to the user manual or installation guide of microinverter)
2. Complete the installation map (refer to the user manual or installation guide of microinverter)
3. Install and power on ECC
4. Create a site on Peimar X Portal
5. Insert LAN into the ethernet port, or insert SIM card into the card slot of ECC, or configure WiFi directly
6. On-site inspection of the site on Peimar X Portal or by App

5. Installation

5.1. Indoor Installation

5.1.1. Installation method 1 (on the wall):

Step 1

Check the box for the items as follows:



1. ECC
2. Bracket
3. Expansion tube
4. Expansion bolt

Step 2

Use the bracket as a template to mark the position of the 3 holes on the wall using a marker, and adjust it even using the spirit level.

Step 3


Drill holes with a drill (drill bit: $\text{Ø} 6 \text{ mm}$), make sure the holes are deep enough (at least 40 mm) for installation.



$\text{Ø}6$ drill
Depth: > 40 mm


Step 4

Insert the expansion tubes in the holes.



Step 5

Place the wall bracket and use self-tapping screws to tighten the bracket. Attach ECC to the bracket. Make sure the back side of ECC is fixed well with buckles on the bracket.




REMARQUE

Prior to step 6, please complete wiring process.

Step 6


Plug in the power adapter to power on ECC, and then plug in the power adapter to the socket.



5.1.2. Installation method 2 (on the platform)


Step 1:

Place ECC on a horizontal platform.




Step 2:

Plug in the power adapter to power on ECC.




Step 3:

Plug in the power adapter to the socket.



5.2. Outdoor Installation

The outdoor installation steps are the same as indoor installation. In addition, a waterproof box is needed to protect ECC.



5.3. APP Operation

The outdoor installation steps are the same as indoor installation. In addition, a waterproof box is needed to protect ECC.

Step 1: Download APP

Scan the QR code to download the monitoring APP



App Store




Google
Play Store



Peimar X Portal


Step 2: Create an account

Click [Sign Up] to create an account, fill in your information and then log in your account.




Step 3: Create a site

Click [+] in the main interface and then fill in the corresponding information to create your site.



Step 4: Add device


Following the last step, you will enter the [Add Device] interface. Input the SN code on the device, and then click [Add Device].



In this step, you will start to configure WiFi. We provide 3 methods: Wi-Fi mode, 4G mode and LAN mode.


Method 1

Choose WiFi mode (the default one) and input your home Wi-Fi account and password. Next, the interface will redirect to the Wi-Fi interface. Please choose the Wi-Fi of your device (WiFi_XXXXXXX, XXXXXX refers to the SN on your device). After connects successfully, the APP will start to configurate.



Method 2

Insert SIM card first and then select [4G] mode. Connect the Wi-Fi of your device, and input [cmnbiot] on the APN bar and select NB-IoT on the Network Deployment bar.



REMARQUE

If you use a white SIM card, please fill [cmnbiot] in the APN column; If you use a black SIM card, please input [cmiot] in the APN column.

Method 3


Insert LAN into the ethernet port to connect ECC to the router in a wired way.

RJ45 terminal



10 - 15 mm

Screw cap

Ensure that all cables are of the same length



Wiring according to 568B standard




5.3.1. Bind microinverter

If you need to bind microinverter, please follow steps as below.

Step 1

Click a site that you need to bind microinverter, click [+] icon, and input or scan the QR code on the microinverter.



REMARQUE

If scanning the QR code step fails, then try to scan the one dimensional code. Scanning one dimensional code may lead to inaccurate scan results).

Step 2

After APP recognize the code, click [Add Device] and then [Next] until the interface pop up [Device added successfully].

5.3.2. Microinverter data

Step 1

Click [Go to Distrib...] to configure WiFi. Fill in your Home WiFi network and password, Select [Next], and connect [WiFi_XXXXXXX] (XXXXXXX refers to the SN of your device).

Step 2

After successfully connecting to WiFi_XXXXXX, system will start to configurate WiFi automatically.

Step 3

Click the specific inverter you bind in the last step to see more details of the device.


5.3.3. On-site inspection

To inspect your site, please click the site, and choose Gateway. Click [Chart], device, [Expand], [Data] or [Graphics] to see the data of your device.




REMARQUE

You can also finish this step by clicking AP button of the ECC.







6 Troubleshooting and Maintenance

6.1. LED Indicator



LED indicator status

Symbol	LED indicator	Definition
	Power	Display the status of electricity power
	Local communication	Display the local communication status
	Peimar Cloud communication	Display the communication with Peimar Cloud
	Warning	Warning important faults

Troubleshooting for ECC + PSI-X1-MIC + meter science

Indicator	Status	Description
RUN	Steady on	Connected to the power
	Steady off	ECC not power on
SERVE1	Steady off	Meter science (Device in one site: microinverter with built-in WiFi + ECC; no communication between microinverter with built-in WiFi and ECC)
	Green light steady on	ECC is connecting to the Peimar X Portal; communication is normal
SERVE2	Green light flashes quickly (1 s)	The AP hotspot of ECC is activated (with the highest priority); after configuration, green light will be steady on
	Red light steady on	Not connected to the router
	Red light flashes quickly (1 s)	Connected to the router; not connected to the server
ALARM	Steady off	Normal; no errors
	Red light flashes quickly (1 s)	Not connected to the meter (no data were transferred)
	Red light steady on	ECC report error

6.2. Maintenance

Regular maintenance is required for the ECC. The table of “Proposal of Maintenance” below lists the operational maintenance for expressing the optimum device performance. More frequent maintenance service is needed in the worse work environment. Please make records of the maintenance.



WARNING

- Only qualified person can perform the maintenance for the ECC.
- Only use the spare parts and accessories approved by Peimar for maintenance.

6.2.1. Maintenance routines

Item	Check Notes	Maintenance Interval
	Check the items mentioned in section 1 “Safety”	
Safety check	The safety check shall be performed by manufacturer’s qualified person who has adequate training, knowledge, and practical experience.	Every 12 months

6.2.2. Upgrading Firmware

Upgrade precautions

- Please make sure that the power supply is normal.
- If the firmware upgrade fails or stops, please unplug the U disk power off the ECC and restart it. Then repeat the upgrade steps.

Upgrade preparation

- Please check the ECC version and prepare a U disk (USB 2.0/3.0) and personal computer before upgrading. Please make sure that the format is FAT FAT 32.
- Please contact our service support to obtain the firmware, and store the firmware in the U disk according to the following path.
 - ECC_Gateway/xxxxxxxxxxxxx_xxx_xxxxxxx_Vxxx.xx_xxxxxxxx.

usb (for example: ECC_Gateway/323101049400_ECC_Gateway_V001.01_20240102.usb)



REMARQUE

VX.XX refers to the file version, XX.XX refers to date.

Upgrade steps

- a) Plug the U-disk into the USB port of ECC.
- b) Wait for ECC to detect the upgrading files and upgrade automatically.

6.2.3 Device Replacement

- a) To disassembling the ECC
 - Pull the power adapter.
 - Unbind the original ECC on the APP and bind a new one in the previous site.

7. Decommissioning

7.1. Disassembling the Gateway

Refer to a. To disassembling the ECC for disassembling the ECC.

7.2. Packing the Gateway

- Load the ECC into the original packing material if possible.
- If the original packing material is not available, you can also use the packing material which meets the following requirements:
 - Suitable for the weight of product.
 - Easy to carry.
 - Be capable of being closed completely.

7.3. Transportation and Storage

If the ECC is not put into use immediately, the transportation and storage requirements needs to be met:

Transportation

Observe the caution signs on the packaging of ECC before transportation.

Pay attention to the weight of ECC. Handle with care.

Wear protective gloves when carrying the equipment by hand to prevent injuries.

When lifting up the ECC, hold the bottom position of the ECC. Keep ECC horizontal in case of falling down due to tilt.

Storage

The ECC must be stored indoors.

Do not remove the original packaging material and check the outer packaging material regularly.

The storage temperature should be between -40°C and $+60^{\circ}\text{C}$. The humidity should be between 5% and 95%.

Stack the ECC in accordance with the caution signs on the ECC carton to prevent their falling down and device damage. Do not place it upside down.

If the ECC has been stored for more than 10 years, it must be checked and tested by professionals prior to use.

7.4. Disposal of the Gateway

Please dispose of the ECCs or accessories in accordance with the disposal regulations for electronic waste applied at the installation site.

8. Technical Data

Power adapter	100~240 V 50/60 HZ 0.8 AAC input 12 V 2 A DC output
Ethernet	10/100 M
Wi-Fi frequency range	2.4 GHz
Wi-Fi EIRP power	19.5 dBm
Degree of protection	IP20
Operating temperature range	-20°C ~ 60°C
Humidity	5% ~ 95%
Dimensions	210 x 113 x 26 mm
Safety	EN 62368-1:2014+A11:2017
EMC	EN 55032: 2015+A11: 2020 EN IEC 61000-3-2: 2019+A1: 2021 EN 61000-3-3: 2013+A2: 2021 EN 55035: 2017+A11: 2020 ETSI EN 301 489-1 V2.2.3: 2019 ETSI EN 301 489-17 V3.2.4: 2020 ETSI EN 301 489-52 V1.2.1: 2021
Radio	ETSI EN 300 328 V2.2.2: 2019 ETSI EN 301 908-1 V15.2.1: 2023 ETSI EN 301 908-13 V13.2.1: 2022
Health	EN IEC 62311: 2020 EN 50665:2017

RF output power	<p>Cat M1: LTE HD-FDD: LTE Cat M1 B1: 21dBm (Conducted) /LTE Cat M1 B2: 21dBm (Conducted) /LTE Cat M1 B3: 21dBm (Conducted) /LTE Cat M1 B4: 21dBm (Conducted) /LTE Cat M1 B5: 21dBm (Conducted) /LTE Cat M1 B8: 21dBm (Conducted) /LTE Cat M1 B12: 21dBm (Conducted) /LTE Cat M1 B13: 21dBm (Conducted) / LTE Cat M1 B18: 21dBm (Conducted) /LTE Cat M1 B19: 21dBm (Conducted) /LTE Cat M1 B20: 21dBm (Conducted) /LTE Cat M1 B25: 21dBm (Conducted) /LTE Cat M1 B26: 21dBm (Conducted) /LTE Cat M1 B271: 21dBm (Conducted) /LTE Cat M1 B28: 21dBm (Conducted) /LTE Cat M1 B66: 21dBm (Conducted) /LTE Cat M1 B85: 21dBm (Conducted) Cat NB2: LTE HD-FDD: LTE Cat NB2 B1: 21dBm (Conducted) /LTE Cat NB2 B2: 21dBm (Conducted) /LTE Cat NB2 B3: 21dBm (Conducted) /LTE Cat NB2 B4: 21dBm (Conducted) /LTE Cat NB2 B5: 21dBm (Conducted) /LTE Cat NB2 B8: 21dBm (Conducted) /LTE Cat NB2 B12: 21dBm (Conducted) /LTE Cat NB2 B13: 21dBm (Conducted) / LTE Cat NB2 B18: 21dBm (Conducted) /LTE Cat NB2 B19: 21dBm (Conducted) /LTE Cat NB2 B20: 21dBm (Conducted) /LTE Cat NB2 B25: 21dBm (Conducted) /LTE Cat NB2 B28: 21dBm (Conducted) /LTE Cat NB2 B66: 21dBm (Conducted) /LTE Cat NB2 B71: 21dBm (Conducted) /LTE Cat NB2 B85: 21dBm (Conducted)</p>
Modulation	BPSK, QPSK, 16QAM
Antenna type	700MHZ~960MHZ/2.39dBi / External Antenna 1710MHZ~2170MHZ/2.39dBi / External Antenna 2300MHZ~2700MHZ/2.39dBi / External Antenna

	LTE HD-FDD B1: Tx: 1920-1980MHz / Rx: 2110-2170MHz
	LTE HD-FDD B2: Tx: 1850-1910MHz / Rx: 1930-1990MHz
	LTE HD-FDD B3: Tx: 1710-1785MHz / Rx: 1805-1880MHz
	LTE HD-FDD B4: Tx: 1710-1755MHz / Rx: 2110-2155MHz
	LTE HD-FDD B5: Tx: 824-849MHz / Rx: 869-894MHz
	LTE HD-FDD B8: Tx: 880-915MHz / Rx: 925-960MHz
	LTE HD-FDD B12: Tx: 699-716MHz / Rx: 729-746MHz
	LTE HD-FDD B13: Tx: 777-787MHz / Rx: 746-756MHz
	LTE HD-FDD B18: Tx: 815-830MHz / Rx: 860-875MHz
	LTE HD-FDD B19: Tx: 830-845MHz / Rx: 875-890MHz
Frequency range	LTE HD-FDD B20: Tx: 832-862MHz / Rx: 791-821MHz
	LTE HD-FDD B25: Tx: 1850-1915MHz / Rx: 1930-1995MHz
	LTE HD-FDD B26: Tx: 814-849MHz / Rx: 859-894MHz
	LTE HD-FDD B27: Tx: 807-824MHz / Rx: 852-869MHz
	LTE HD-FDD B28: Tx: 703-748MHz / Rx: 758-803MHz
	LTE HD-FDD B31: Tx: 452.5-457.5MHz / Rx: 462.5-467.5MHz
	LTE HD-FDD B66: Tx: 1710-1780MHz / Rx: 2110-2180MHz
	LTE HD-FDD B71: Tx: 663-698MHz / Rx: 617-652MHz
	LTE HD-FDD B72: Tx: 451-456MHz / Rx: 461-466MHz
	LTE HD-FDD B73: Tx: 450-455MHz / Rx: 460-465MHz
	LTE HD-FDD B85: Tx: 698-716MHz / Rx: 728-746MHz

/// PEIMAR



info@peimar.com | www.peimar.com